


## Cable Adapters

### Etherlite, RJ-45 to DB-9 Console Adapter


For use with Etherlite 2, 80, 160, 162, 32 – All Models

Digi Cable Adapters allow you to connect your serial devices using commercially available CAT 5 cable of any length. Simply plug standard CAT 5 cable into your Digi Product, connect a Cable Adapter to the other end and plug the adapter into your device.


From RJ-45	Signal	Direction	Signal	To DB-9
1	RTS	→	CTS	8
3	DCD	←	DTR	4
4	RxD	←	TxD	3
5	TxD	→	RxD	2
6	SG	↔	SG	5
7	DTR	↔	DCD	1
			DSR	6
8	CTS	←	RTS	7



Female RJ-45  
8-pin



Female DB-9



Cable Adapter not to scale

\* Arrows indicate which direction the signal is flowing

#### Notes:

- All RJ45 cable adapters are 8-pin.
- This cable utilizes the RTS signal of the serial device for hardware flow control (RTS / CTS).

Digi Part Number 76000461 Etherlite DB9F Console Adapter (single-pack)