# Vibration Sensor with Linear Output or Manual Setting

D7F

# Detects Changes in Machine Vibration

- ON/OFF output can be set and checked quickly and easily from the vibration level meter.
- Vibration waveforms can be checked using the AC monitor output.
- The IP67 rating enables use in harsh environments.
- Selectable acceleration and speed available with Linear Output Models.
- Five operating modes ensure highly accurate error detection.



Be sure to read Safety Precautions on page 1218.



# Vibration Ordering Information

Soncore					
36113013	C				
Inclination	Sensors				
Sensors	Appearance	Туре	Cable length	Model	
Liquid Leakage Sensors		Manually set	5 m	D7F-S01-05	
Liquid Leakage		Wandally Set	10 m	D7F-S01-10	
Sensor Accessories		Linear output	5 m	D7F-S03-05	

Other Controllers

Appearance	Туре	Model
	Manually set	D7F-C01
	Linear output	D7F-C03

D7F

# **Ratings and Specifications**

#### Sensors Manually Set Models D7F-S01-05/D7F-S01-10

Sensitivity	5.1 mV/(m/s <sup>2</sup> ) (typical)	
Detection frequency	20 Hz to 2 kHz (±3 dB)	
Resonance frequency	Approx. 5 kHz	
Max. acceleration	784 m/s <sup>2</sup>	
Shock resistance	29,400 m/s <sup>2</sup>	
Vibration resistance	10 Hz to 2 kHz, 2-mm single amplitude or 392 m/s <sup>2</sup>	
Degree of protection	IP67 (IEC 60529)	
Insulation resistance	20 $M\Omega$ min. at 100 VDC between the case and all terminals	
Dielectric strength	1,000 VAC between the case and all terminals at 50/60 Hz for 1 min	
Ambient temperature	-25 to 70°C (with no icing or condensation)	
Ambient humidity	25% to 95% (with no icing or condensation)	
Cable length	5 m, 10 m	
Tightening torque	4.4 to 5.4 N⋅m	
Weight	Approx. 40 g (excluding the cable)	

#### Linear Output Model D7F-S03-05

Operating temperature range	–25 to 70°C	
Operating humidity range	25% to 95%	
Storage temperature	–40 to 80°C	
Connectable vibration sensor Controller	D7F-C03	
Vibration resistance	10 to 150 Hz, 0.35-mm single amplitude or 50 m/s <sup>2</sup>	
Shock resistance	150 m/s <sup>2</sup>	
Degree of protection	IP67 (IEC 60529)	
Sensitivity *	5.1mV/(m/s <sup>2</sup> ) ±20 (at 100 Hz)	
Frequency range	10 to 2,000 Hz (±3 dB)	
Max. acceleration	98 m/s² (rms)	
Weight	Approx. 40 g (excluding the cable)	
* Songer obergeteristic		

\* Sensor characteristic

nclination/ )ther Senso

Vibration Sensors

Inclination Sensors

Liquid Leakage Sensors

Liquid Leakage Sensor Accessories

Other Information

D7F

# . 11

	Manually Set Model D7F-C01			
	Frequency range	20 Hz to 20 kHz		
	Power supply voltage range	12 to 24 VDC±10% (10.8 to 26.4 VDC)		
	Current consumption	200 mA max.		
	Relay output	SPDT (30 VDC, 3 A or 250 VAC, 3 A resistive load)		
	Monitor output *	5.1 mV (m/s <sup>2</sup> )		
	Operations	Mode selector (MODE) Gain selector (GAIN) Sensitivity adjuster (SENS)		
ON delay		0.1 s min. in Continuous Vibration Detection Mode 5 ms in Intermittent Vibration Detection Mode		
Ľ	OFF delay	1 s		
	Vibration level indicator	10-level meter		
	Additional functions	Relay output for a sensor cable disconnection and a flashing level meter		
	Vibration resistance	Destruction: 10 to 150 Hz, 0.75-mm single amplitude, maximum acceleration of 98m/s <sup>2</sup>		
	Shock resistance	Destruction: 294 m/s <sup>2</sup>		
_	Ambient temperature	Operating: –20 to 60°C (with no icing or condensation)		

\* The following table shows typical AC monitor outputs.

Ambient humidity

**Vibration Sensor** 

Connectable

Weight

Range	Acceleration (X value)
 × 1	5.1 mV/(m/s <sup>2</sup> )
× 3	15.3 mV/(m/s <sup>2</sup> )
× 10	51 mV/(m/s <sup>2</sup> )
× 30	153 mV/(m/s <sup>2</sup> )
× 100	510 mV/(m/s <sup>2</sup> )

Operating: 25% to 95%

D7F-S01-□□

Approx. 120 g

(with no icing or condensation)

#### **Linear Output Model** D7F-C03

-			
Power supply voltage range			12 to 24 VDC±10% (10.8 to 26.4 VDC)
Current consumption			100 mA max.
Opera	ating temper	rature range	–10 to 55°C
Operating humidity range			25% to 85%
Stora	ge temperat	ure range	–25 to 65°C
Conn	ectable Vibr	ation Sensor	D7F-S03-05
Vibra	tion resistar	ice	10 to 150 Hz, 0.35-mm single amplitude or 50 m/s <sup>2</sup>
Shoc	k resistance	l.	150 m/s <sup>2</sup>
	Analog	Output range	4 to 20 mA
	DC	Allowable load resistance	300 Ω max.
		Output configuration	NPN open collector
		Residual voltage	1.5 V max.
	Transistor	Leakage current	0.1 mA max.
		Max. load voltage	26.4 VDC
		Max. sink current	100 mA max.
Out-		Min. output time	50 ms min
put	AC monitor *	ACC (reference values)	× 1 range, 5.1 mV/(m/s <sup>2</sup> ) (typical) × 5 ranges, 25.5 mV/(m/s <sup>2</sup> ) (typical) × 10 ranges, 51 mV/(m/s <sup>2</sup> ) (typical)
		VEL (reference values)	× 1 range, 25.4 mV/(mm/s) (typical) × 5 ranges, 127 mV/(mm/s) (typical) × 10 ranges, 254 mV/(mm/s) (typical)
		Impedance	10 kΩ
Weight			Approx. 120 g

\* The AC monitor output is used to check simple waveforms. Do not use it for precision measurements or waveform analysis. The following diagram shows the monitor output voltage.

		ACC (acceleration)	VEL (velocity)
_	× <b>1</b>	0 to 98 m/s <sup>2</sup>	0 to 20 mm/s
Range (rms)	× 5	0 to 19.6 m/s <sup>2</sup>	0 to 4 mm/s
< - <i>y</i>	× 10	0 to 9.8 m/s <sup>2</sup>	0 to 2 mm/s
Frequency range		20 to 2,000 Hz	10 to 1,000 Hz
Linearity		±5% F.S. (at 100 Hz)*	
Gain error		±5% F.S. (at 100 Hz)*	
Zero point offset		4±0.2 mA (at 20°C)*	

\* Controller characteristic

# Nomenclature

(4)

(1)

(2)

### **Manually Set Model**

 D7F-C01 Vibration Sensor Controller Vibration Sensor Controllers process signals from Vibration Sensors, detect errors, and produce an external output.

Monitor output

-Relay output

(5)

(6)

(7)

(3)

 $\mathbf{G}$ 

**Sensor Frequency Characteristics** 

20 Hz

2 kHz

+ 4 VAC (Impedance: 10 Ω)

#### Operations

#### (1) MODE Selector

Selects the waveform processing mode.

MODE	Waveform		Application example
А		20 Hz to 20 kHz	General purpose, monitoring, etc.
В	Continu- ous	20 Hz to 200 Hz	Imbalance, deviation, etc.
С	vibration detection	200 Hz to 2 kHz	High-speed rotating object error, etc.
D		2 kHz to 20 kHz	Bearing damage, etc.
Е	Intermittent vibration detection		Contact, shock, etc.

#### Applicable in Wet Environments

A quick-mounting magn is provided to help

locate the detection

position

5 kHz (Resonance point) Frequency

The IP67 (dust-proof and immersion-proof) rating for Vibration Sensors enables application in harsh environments, including those exposed to water.

#### (2) GAIN Selector (1 to 100 x)

The GAIN Selector is used to change the signal strength.

Example: Increasing signal strength

#### (3) Sensitivity Adjuster

The sensitivity adjuster is used to change the threshold setting.

#### Indicators

Th

Vib

#### (4) LEVEL METER

The Level Meter indicator clearly shows the vibration level.

(5) POWER The POWER indicator is lit when the power is ON.

operating.

(6) OUTPUT Vibration Sensors use piezoelectric ceramic devices to convert vibration to (7) OVER electrical signals.

D7F-S01-00

Vibration Sensor

The OVER indicator is lit when vibration is detected.

The OUTPUT indicator is lit when the output relay is

#### Terminology

The following diagram shows ON and OFF delay times.



Vibration Sensors

Inclination

Sensors Liquid Leakage

Sensors Liquid Leakage

Sensor Accessories

Other Information

#### Linear Output Model D7F-C03

Outpu

0 dE



#### Operations

#### (1) RUN/SET Selector

The RUN/SET Selector sets the Level Meter indication to RUN or SET. (2) ACC/VEL Selector

The ACC/VEL Selector sets the operating mode to acceleration or velocity. (3) GAIN Selector

The GAIN Selector changes the signal strenath.

(4) Threshold Adjuster

The Threshold Adjuster sets the threshold value.

#### Indicators

#### (5) Level (10 levels)

RUN: Indicates vibration magnitude. SET: Indicates threshold settings.

Level Meter levels	Vibration level and threshold settings
10	95% or higher F.S.
9	85% to 95% F.S.
8	75% to 85% F.S.
7	65% to 75% F.S.
6	55% to 65% F.S.
5	45% to 55% F.S.
4	35% to 45% F.S.
3	25% to 35% F.S.
2	15% to 25% F.S.
1	5% to 15% F.S.

Note: Use the Level Meter indicator strictly as a guideline.

#### (6) PWR/ALM Indicator

Power ON: Green light Sensor error: Red light

#### (7) OUTPUT Indicator

The output transformer operates and the OUTPUT indicator lights at vibration levels exceeding the threshold setting. The output and indications are the same whether RUN or SET is selected.

(8) SET Indicator

The SET Indicator is lit when SET is selected from the RUN/SET selector.

D7F

# **Safety Precautions**

#### Refer to Warranty and Limitations of Liability on page F-2.

#### Precautions for Safe Use

Do not perform wiring work or touch any terminals with power supplied. Doing so may result in electric shock.

#### Precautions for Correct Use

Do not use this product in atmospheres or environments that exceed product ratings.

#### **Sensor Installation**

• Wipe the mounting surface to remove all dirt and use a No. 17 wrench to secure the D7F in place. Optimum tightening torque: 4.4 to 5.4 N·m

Mounting hole dimensions: M6 holes, Depth: 7 mm min.

- The D7F may not operate correctly if it is not secured with the proper torque or the mounting surface is not cleaned properly prior to installation.
- The quick-mounting magnet is provided to help locate the proper detection position. Make sure the D7F is secured with screws for long-term applications.
- The quick-mounting magnet will not hold the D7F if the magnet is installed vertically or backwards.

9.2+0.2

#### **Quick-mounting Magnet Dimensions**



#### **Sensor Mounting Direction**

• Mount the D7F as indicated by the circle in the diagram below.



Handling the Sensor

- The Sensor Cable can be cut to any length, but it cannot be extended.
- Do not disassemble the D7F. Otherwise, it may not operate properly.
- Make sure all wiring is correct and be careful not to short wires while wiring.
- Do not install the D7F in locations subject to oil. Otherwise, the rubber seal will deteriorate, allowing liquids such as oil or water to enter the D7F, which may cause it to fail.
- The D7F should be connected only to a specified Controller, such as the D7F-C01 or D7F-C03.

#### Handling the Controller

- The Controller should be connected only to a specified Sensor, such as the D7F-S01- or D7F-S03- .
- Do not attempt to disassemble the Controller. Otherwise, it may not operate properly.
- Do not install the Controller in a dusty location or one subject to water or oil.
- Do not mount the Controller directly to any source of vibration.

#### Removing the D7F from a DIN Track

 Remove the D7F from a DIN Track as shown in the diagram on the right.



D7F

Vibration

Sensors

Inclination

Liquid Leakage

Sensors

Sensors Liquid Leakage Sensor Accessories Other Information

## Dimensions

#### Sensors





#### D7F-S03-05





5,000±100

1.5

6

6.5±0.4 5

5,000±100

55)

17\_0.25

35±5

Mounting screw (M6)

#### Controllers

D7F-C01



Cat. No. F835-E1-01 In the interest of product improvement, specifications are subject to change without notice.