


# Grove - 6-Axis Accelerometer&Compass V2.0



The Grove –6-Axis Accelerometer&Compass V2.0 is a 3-axis accelerometer combined with a 3-axis magnetic sensor. It is an upgraded version of Grove - 6-Axis Accelerometer&Compass V1.0 and based on the sensor module LSM303D which has a selectable linear acceleration full scale range of  $\pm 2g$  /  $\pm 4g$  /  $\pm 8g$  /  $\pm 16g$  and a selectable magnetic field full scale range of  $\pm 2$  /  $\pm 4$  /  $\pm 8$  /  $\pm 12$  gauss. Both the magnetic parts and the accelerometer parts can be powered down separately to reduce the power consumption. The Arduino can get these data via the I2C interface with the given library for this module.

## Specifications

- Input Voltage: 5V
- I2C Interface and selectable SPI Interface
- Measuring scale selectable
- 6D orientation detection
- 2 independent programmable interrupt generators
- Power-down mode
- I2C Address 0x1E(default), or 0x1D

### Note

If you want to use multiple I2C devices, please refer to [Software I2C](#).

### Tip

More details about Grove modules please refer to [Grove System](#)


## Platforms Supported

Arduino	Raspberry Pi	BeagleBone	Wio	LinkIt ONE
				

### Caution

The platforms mentioned above as supported is/are an indication of the module's software or theoretical compatibility. We only provide software library or code examples for Arduino platform in most cases. It is not possible to provide software library / demo code for all possible MCU platforms. Hence, users have to write their own software library.

## Hardware Overview



- ① Grove interface, connect to I2C
- ② SPI Interface
- ③ I2C or SPI select pad(default is I2C), if want to use SPI, disconnect this pad
- ④ Interrupt digital output
- ⑤ Address select pad, default connected b and a address is 0x1E, if connect b and c address is 0x1D, if want to use SPI, disconnect this pad to either side.

## Getting started




The LSM303D is a 6D sensor module that contains a 3D accelerometer and a 3D magnetic sensor. It has an I2C digital interface so that the analog to digital converter is avoided.

The MCU can collect 6D sensor data directly through the I2C interface.OK, let's start on using this LSM303D 6D sensor module.


## Play with Arduino

### Hardware

- **Step 1.** Prepare the below stuffs:

Seeeduino V4.2	Base Shield	Grove-6-Axis_AccelerometerAndCompass_V2.0
		

- **Step 2.** Connect Grove-6-Axis\_AccelerometerAndCompass\_V2 to port **I2C** of Grove-Base Shield.
- **Step 3.** Plug Grove - Base Shield into Seeeduino.
- **Step 4.** Connect Seeeduino to PC via a USB cable.



### Note

If we don't have Grove Base Shield, We also can directly connect this module to Seesduino as below.

Seesduino_v4	Grove-6-Axis_AccelerometerAndCompass_V2
5V	VCC
GND	GND
SDA	SDA
SCL	SCL

### Software

**Step 1.** Download the [library](#) from Github.

**Step 2.** Refer [How to install library](#) to install library for Arduino.

**Step 3.** Create a new Arduino sketch and paste the codes below to it or open the code directly by the path:File -> Example ->Accelerometer\_Compass->Accelerometer\_Compass.

**Step 4.** Upload the code. If you do not know how to upload the code, please check [how to upload code](#).

## Here is the code

```
/* LSM303DLM Example Code base on LSM303DLH example code by Jim Lindblom
1SparkFun Electronics

2  date: 9/6/11
   license: Creative commons share-alike v3.0
3
   Modified by:Frankie.Chu
4  Modified by:Jacky.Zhang 2014-12-11: Ported to 6-Axis
   Accelerometer&Compass of Seeed Studio
5  Modified by:Jacky.Zhang 2015-1-6: added SPI driver

6  Summary:
   Show how to calculate level and tilt-compensated heading using
7  the snazzy LSM303DLH 3-axis magnetometer/3-axis accelerometer.

8  Firmware:
   You can set the accelerometer's full-scale range by setting
9  the SCALE constant to either 2, 4, or 8. This value is used
   in the initLSM303() function. For the most part, all other
10 registers in the LSM303 will be at their default value.

11 Use the write() and read() functions to write
   to and read from the LSM303's internal registers.
12
   Use getLSM303_accel() and getLSM303_mag() to get the acceleration
13 and magneto values from the LSM303. You'll need to pass each of
   those functions an array, where the data will be stored upon
14 return from the void.

15 getHeading() calculates a heading assuming the sensor is level.
   A float between 0 and 360 is returned. You need to pass it a
16 array with magneto values.

17 getTiltHeading() calculates a tilt-compensated heading.
   A float between 0 and 360 degrees is returned. You need
18 to pass this function both a magneto and acceleration array.

19 Headings are calculated as specified in AN3192:

20http://www.sparkfun.com/datasheets/Sensors/Magneto/Tilt%20Compensated%20Compass.pdf
21*/

22/*
   hardware & software comment
23I2C mode:
   1, solder the jumper "I2C EN" and the jumper of ADDR to 0x1E
242, use Lsm303d.initI2C() function to initialize the Grove by I2C
   SPI mode:
251, break the jumper "I2C_EN" and the jumper ADDR to any side
   2, define a pin as chip select for SPI protocol.
263, use Lsm303d.initSPI(SPI_CS) function to initialize the Grove by SPI
   SPI.h sets these for us in arduino
27const int SDI = 11;
```

```

const int SDO = 12;
28const int SCL = 13;
  */
29
#include <LSM303D.h>
30#include <Wire.h>
#include <SPI.h>
31
/* Global variables */
32int accel[3]; // we'll store the raw acceleration values here
int mag[3]; // raw magnetometer values stored here
33float realAccel[3]; // calculated acceleration values here
float heading, titleHeading;
34
#define SPI_CS 10
35
void setup()
36{
    char rtn = 0;
37    Serial.begin(9600); // Serial is used for debugging
    Serial.println("\r\npower on");
38    rtn = Lsm303d.initI2C();
    //rtn = Lsm303d.initSPI(SPI_CS);
39    if(rtn != 0) // Initialize the LSM303, using a SCALE full-scale range
    {
40        Serial.println("\r\nLSM303D is not found");
        while(1);
41    }
    else
42    {
        Serial.println("\r\nLSM303D is found");
43    }
}
44
void loop()
45{
    Serial.println("\r\n*****");
46    //getLSM303_accel(accel); // get the acceleration values and store
    them in the accel array
47    Lsm303d.getAccel(accel);
    while(!Lsm303d.isMagReady()); // wait for the magnetometer readings to
48be ready
    Lsm303d.getMag(mag); // get the magnetometer values, store them in mag
49
    for (int i=0; i<3; i++)
50    {
        realAccel[i] = accel[i] / pow(2, 15) * ACCELE_SCALE; // calculate
51real acceleration values, in units of g
    }
52    heading = Lsm303d.getHeading(mag);
    titleHeading = Lsm303d.getTiltHeading(mag, realAccel);
53
    printValues();
54
    delay(200); // delay for serial readability
55}

```

```
56 void printValues()
   {
57   Serial.println("Acceleration of X,Y,Z is");
   for (int i=0; i<3; i++)
58   {
       Serial.print(realAccel[i]);
59   Serial.println("g");
   }
60   //print both the level, and tilt-compensated headings below to compare
   Serial.println("The clockwise angle between the magnetic north and x-
61axis: ");
   Serial.print(heading, 3); // this only works if the sensor is level
62   Serial.println(" degrees");
   Serial.print("The clockwise angle between the magnetic north and the
63projection");
   Serial.println(" of the positive x-axis in the horizontal plane: ");
64   Serial.print(titleHeading, 3); // see how awesome tilt compensation
   is?!
65   Serial.println(" degrees");
   }
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
```

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

10

0

10

1

10

2

10

3

10

4

10

5

10

6

10

7

10

8

10

9

11

0

11

1

11


2

11



3  
11  
4  
11  
5  
11  
6  
11  
7  
11  
8  
11  
9  
12  
0  
12  
1

**Step 5.** Open the serial monitor, you will see the output result of Color Sensor as shown below:



**Step 6.** You can see the acceleration values and the clockwise angle between the magnetic north and x-axis.




The X/Y/Z shows the 3 axis acceleration; and then the angle between the magnetic north and x-axis calculated.

And also the the angle between the magnetic north and the projection of positive x-axis calculated.


## Play With Raspberry Pi

### Hardware

- **Step 1.** Prepare the below stuffs:

Raspberry pi	GrovePi_Plus	Grove-6-Axis_AccelerometerAndCompass_V2.0
		

- **Step 2.** Plug the GrovePi\_Plus into Raspberry.
- **Step 3.** Connect Grove-6-Axis\_AccelerometerAndCompass\_V2.0 to **I2C** port of GrovePi\_Plus.
- **Step 4.** Connect the Raspberry to PC through USB cable.



## Software

- **Step 1.** Follow [Setting Software](#) to configure the development environment.
- **Step 2.** Git clone the Github repository.

```
1cd ~
2git clone https://github.com/DexterInd/GrovePi.git
```

- **Step 3.** Execute below commands to use this sensor

```
1cd ~/GrovePi/Software/Python/grove_6axis_acc_compass
2python grove_6axis_accel_compass_example.py
```

Here is the code of example:

```
1#!/usr/bin/env python
2#
3# GrovePi example for using the Grove - 6-Axis Accelerometer&Compass
4v2.0(http://www.seeedstudio.com/depot/Grove-6Axis-AccelerometerCompass-v20-5p-2476.html)
5#
6#
7# The GrovePi connects the Raspberry Pi and Grove sensors. You can learn
8more about GrovePi here: http://www.dexterindustries.com/GrovePi
9#
10# Have a question about this library? Ask on the forums here:
11http://forum.dexterindustries.com/c/grovepi
12#
13'''
14## License
15The MIT License (MIT)
16GrovePi for the Raspberry Pi: an open source platform for connecting Grove
17Sensors to the Raspberry Pi.
18Copyright (C) 2017 Dexter Industries
19Permission is hereby granted, free of charge, to any person obtaining a
20copy
21of this software and associated documentation files (the "Software"), to
22deal
23in the Software without restriction, including without limitation the
24rights
25to use, copy, modify, merge, publish, distribute, sublicense, and/or sell
26copies of the Software, and to permit persons to whom the Software is
27furnished to do so, subject to the following conditions:
28The above copyright notice and this permission notice shall be included in
29all copies or substantial portions of the Software.
30THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR
31IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY,
32FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE
33AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER
34LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING
35FROM,
36OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN
37THE SOFTWARE.
```

```

38'''
39import lsm303d
40
41try:
42    acc_mag=lsm303d.lsm303d()
43
44    while True:
45
46        # Get accelerometer values
47        acc=acc_mag.getRealAccel()
48
49        # Wait for compass to get ready
50        while True:
51            if acc_mag.isMagReady():
52                break
53
54        # Read the heading
55        heading= acc_mag.getHeading()
56
57        print("Acceleration of X,Y,Z is %.3fg, %.3fg, %.3fg"
58              %(acc[0],acc[1],acc[2]))
59        print("Heading %.3f degrees\n" %(heading))
60
61except IOError:
62    print("Unable to read from accelerometer, check the sensor and try
63          again")

```

Here is the result:


```

pi@raspberrypi: ~/Desktop/GrovePi/Software/Python/grove_6axis_acc_compass
Heading 323.901 degrees
Acceleration of X,Y,Z is 0.166g, 0.290g, 1.039g
Heading 323.230 degrees
Acceleration of X,Y,Z is 0.165g, 0.288g, 1.023g
Heading 323.107 degrees
Acceleration of X,Y,Z is 0.164g, 0.287g, 1.041g
Heading 322.561 degrees
Acceleration of X,Y,Z is 0.168g, 0.287g, 1.034g
Heading 322.886 degrees
Acceleration of X,Y,Z is 0.172g, 0.287g, 1.032g
Heading 323.001 degrees
Acceleration of X,Y,Z is 0.167g, 0.288g, 1.032g
Heading 323.747 degrees
Acceleration of X,Y,Z is 0.165g, 0.289g, 1.040g
Heading 323.601 degrees


```

## References

Click [here](#) to know more about this parameter.



AM06785v1




AM06777v1

## Notes

1. All ST MEMS accelerometers are factory calibrated, allowing the user to avoid any further calibration for most of the applications. However, to reach a heading accuracy of below 2°, an easy calibration procedure is needed.

2. When test The clockwise angle between the magnetic north and x-axis, you can align the device X<sub>a</sub> axis to any direction, but do not make it face down. Refer to the below picture:



## Resources

- **[Library]** [6-Axis Accelerometer&Compass v2.0 Library for arduino](#)
- **[Library]** [6-Axis Accelerometer&Compass v2.0 Library for raspberry pi](#)
- **[Datasheet]** [LSM303D\\_datashet](#)
- **[Eagle]** [6-Axis Accelerometer&Compass v2.0 eagle file](#)

## Tech Support

Please submit any technical issue into our [forum](#).