E3JM

CSM_E3JM_DS_E_12_1


Model Contribute to Overall Cost Reduction

E3JM Terminal Block Models

• Easy to wire and adjust.



For the most recent information on models that have been certified for safety standards, refer to your OMRON website.



Ordering Information

Sensors (Refer to Dimensions on page 9.)

								Red light Infrared light			
Sensing method	Appearance	Connection method	Sensing distance		Operation mode	Output configuration	Functions	Model			
		Terminal block				Relay		E3JM-10M4-N Emitter: E3JM-10L-N Receiver: E3JM-10DM4-N			
Through- beam						nelay	Timer	E3JM-10M4T-N Emitter: E3JM-10L-N Receiver: E3JM-10DM4T-N			
(Emitter + Receiver) *) 10 m	Light-ON Dark-ON (switch selectable)	DC SSR		E3JM-10S4-N Emitter: E3JM-10L-N Receiver: E3JM-10DS4-N			
							Timer	E3JM-10S4T-N Emitter: E3JM-10L-N Receiver: E3JM-10DS4T-N			
Retro- reflective									Relay	 Timer	E3JM-R4M4 E3JM-R4M4T
with MSR function	€39-R1 (provided)			4 m	4 m		DC SSR	 Timer	E3JM-R4S4 E3JM-R4S4T		
Diffuse- reflective					-	Relay	 Timer	E3JM-DS70M4 E3JM-DS70M4T			
			700 mm			DC SSR	 Timer	E3JM-DS70S4 E3JM-DS70S4T			

*Through-beam Sensors are sold in sets that include both the Emitter and Receiver. An order for the Emitter or Receiver alone cannot be accepted.
Note: UL-listed models have the -US suffix. The model number for an E3JM Through-beam Sensor ends in "-US" (and not in "-N"). (Example: E3JM-10M4-US). Tightening nuts, washers, and rubber bushings are not provided with these models.
Change: Shape of the E3JM conduit socket

Accessories (Order Separately)

Slit (A Slit is not provided with the Sensor for through-beam. Order a Slit separately if required.) (Refer to Dimensions on page 9.)

Slit width	Sensing distance		Minimum detect- able object (reference value)	Model	Quantity	Remarks
1 mm × 20 mm	E3JM-10□4(T)-N	1.2 m	1-mm dia.	E39-S39	1 Slit each for the Emitter and Receiver (2 Slits total)	(Seal-type long slit) Can be used with the E3JM-10□4(T)-N Models.

Reflectors (A Reflector is required for each Retro-reflective Sensor.)

The E39-R1 Reflector is provided with the Sensor. Order other Reflectors separately if required. (Refer to Dimensions on E39-L/E39-S/E39-R.)

Name	Sensir	Model	Quantity	Remarks	
Reflectors	E3JM-R4□4(T)	4 m	E39-R1	1	Provided with the E3JM-R4□4(T)

Note: Refer to Reflectors on E39-L/E39-S/E39-R for details.

Mounting Bracket

Some Mounting Brackets are provided with the Sensor. Order other Mounting Brackets separately if required. (Refer to E39-L/E39-S/E39-R)

Appearance	Model	Quantity	Remarks
	E39-L53	1	Provided with the E3JM.
	E39-L51	1	Mounting Bracket designed for changing from he E3A-M, E3A2, E3A3, OA-5, or OA-5N to the E3JM.

Note: 1. When using a Through-beam Sensor, order one Connector for the Receiver and one for the Emitter. 2. Refer to *Mounting Brackets* on *E39-L/E39-S/E39-R* for details.

Ratings and Specifications

	Sensing method	Through-beam model	Retro-reflective model (with MSR function)	Diffuse-reflective model			
Item	Model	E3JM-10□4(T)-N	E3JM-R4□4(T)	E3JM-DS70□4(T)			
Sensing distance		10 m	4 m (When using E39-R1)	White paper (200 \times 200 mm): 700 mm			
Standard sensi	ng object	Opaque: 14.8-mm dia. min.	Opaque: 75-mm dia. min.				
Differential trav	el	-		20% max. of sensing distance			
Directional ang	le	Both Emitter and Receiver 3° to 20°	1° to 5°				
Light source (w	avelength)	Infrared LED (950 nm)	Red LED (660 nm)	Infrared LED (950 nm)			
Power supply v	oltage	12 to 240 VDC±10%, ripple (p-p): 1 24 to 240 VAC±10%, 50/60 Hz	10% max.				
Power con-	DC	3 W max. (Emitter 1 W max. Receiver 2 W max.)	2 W max.				
sumption	AC	3 W max. (Emitter 1 W max. Receiver 2 W max.)	2 W max.				
Control output			del): SPDT, 250 VAC, 3A (cos¢=1) nodel): 48 VDC, 100 mA max. (resi				
Life	Mechanical	50,000,000 times min. (switching frequency: 18,000 times/h)					
expectancy (relay output)	Electrical	100,000 times min. (switching frequ	uency: 1,800 times/h)				
· · · /	Relay output	(E3JM-00M4 (T) models) Operate	or reset: 30 ms max.				
Response time	DC SSR output	(E3JM-DS4 (T) models) Operate or reset: 5 ms max.					
Sensitivity adju	stment			One-turn adjuster			
Timer function *		ON-delay/OFF-delay/One-shot delay switch selectable Delay time: 0.1 to 5 s (adjustable), only for E3JM-DD4T					
Ambient illumination (Receiver side)		Incandescent lamp: 3,000 lx max.					
Ambient tempe	rature range	Operating: -25°C to 55°C, Storage: -30°C to 70°C (with no icing or condensation)					
Ambient humid	ity range	Operating: 45% to 85% (with no condensation), Storage: 35% to 95% (with no condensation)					
nsulation resis	tance	20 MΩ min. at 500 VDC					
Dielectric stren	gth	2,000 VAC, 50/60 Hz for 1 min.					
Vibration	Destruction	10 to 55 Hz, 1.5-mm double amplitude for 2 hours each in X, Y, and Z directions					
resistance	Malfunction	0 to 55 Hz, 1.5-mm double amplitude for 2 hours each in X, Y, and Z directions					
Shock	Destruction	500 m/s ² 3 times each in X, Y, and	Z directions				
resistance	Malfunction	100 m/s ² 3 times each in X, Y, and Z directions					
Degree of prote	ction	IEC 60529: IP66					
Connection method		Terminal block					
Weight (packed state)		Approx. 270 g Approx. 160 g					
	Case	ABS (Acrylonitril Butadiene Styrene)					
	Lens	Methacrylic resin					
Material	Cover	Polycarbonate					
	Mounting Bracket	Iron					
Accessories		Mounting Bracket (with screw), Nut ing -US Models), Instruction manua					


*The timer cannot be disabled for models with timer functions (E3JM-004T).


Engineering Data (Reference Value)

Parallel Operating Range

Through-beam

E3JM-10_4(T)-N





1.5

2.5

2

3.5

3

Distance

X (m)

Through-beam

20

0

-20


-40

-60

Retro-reflective

0.5


Retro-reflective



Operating Range


Diffuse-reflective

E3JM-DS70 4(T) 60



Excess Gain Ratio vs. Set Distance


Through-beam




Downloaded from Arrow.com.

Sensing Object Size vs. Sensing Distance

Diffuse-reflective E3JM-DS70□4(T)





I/O Circuit Diagrams

Relay Output Models

Model	Timing chart	Output circuit		
E3JM-10M4(T)-N *1 E3JM-R4M4(T) E3JM-DS70M4(T)	Incident light No incident light Indicator (red) *2 OFF L-ON (Ta) ON D-ON (Ta) OFF Refer to page 7 for information on Sensors with timers (T).	Photoelectric Sensor main circuit Built-in Relay: G6C)		

DC SSR Output Models

Model	Timing chart	Output circuit
E3JM-10S4(T)-N *1 E3JM-R4S4(T) E3JM-DS70S4(T)	Incident light No incident light Indicator (red) *2 OFF L-ON (Ta) ON D-ON (Ta) OFF D-ON (Ta) OFF Refer to page 7 for information on Sensors with timers (T).	24 to 240 VAC 12 to 240 VDC

Note: Connect terminal 1 to any polarity and terminal 2 to the power supply because there is no polarity on the Emitter side.
 *1. Models numbers for Through-beam Sensors (E3JM-10_4(T)-N) are for sets that include both the Emitter and Receiver. The model number of the Emitter is always E3JM-10L-N. Add a "D" to get the model number of the Receiver (example: E3JM-10DM4-N). Confirm the model numbers of the Emitter and Receiver in *Ordering Information*.
 *2. This is the light indicator on Sensors without a timer and the operation indicator on Sensors with a timer.

Safety Precautions

Refer to Warranty and Limitations of Liability.

🔥 WARNING

This product is not designed or rated for ensuring safety of persons either directly or indirectly. Do not use it for such purposes.

Precautions for Correct Use

Do not use the product in atmospheres or environments that exceed product ratings.

Designing

Operation

Note: The white part of the DIP switch indicates which setting is selected.

	Switch configuration	Switch selection			Timing charts		
Models without timer	MODE 0++1 D-ON L-ON 0peration selector	D·ON LON DČ outpu element C MODE 0 ++ 1 Dark-ON,		, Relay ON It switching	L-ON OFF		
Models with timer	MODE 0++1 D-ON TIMER D-ON TIMER D-ON Sw1 Sw2 Operation Selector Selector switch <u>for</u>	ON-delay MODE 0++1 D-ON TIMER Both SW1 and SW2 at "0." Note: The operation without a time		One-shot delay MODE 0 ↔ +1 D-ON TIMER Only SW1 at "1," which overrides either setting of SW2. We as that for models	ON-delay	OFF-delay	One-shot delay

Output Relay Contact

If E3JM is connected to a load with contacts that spark when the load is turned OFF (e.g., a contactor or valve), the normally-closed side may be turned ON before the normally-open side is turned OFF or vice-versa. If both normally-open output and normally-closed output are used simultaneously, apply an surge suppressor to the load.

Refer to OMRON's PCB Relays Catalog (X33) for typical examples of surge suppressors.

• Wiring


Connecting and Wiring

- \bullet We recommend connecting a cable with a conductor cross-section of 0.3 $\rm mm^2$ and an outer diameter of 6 to 8 mm.
- Be sure to firmly tighten the cover in order to maintain waterproof and dustproof properties. The screw size of the conduit sockets is shown in the following table.

Model	Conduit socket thread size
E3JM-	PF1/2


• When using the DC SSR output model, the total of the load current for the Light-ON output (NO) and that for the Dark-ON (NC) should be 100 mA max. If the total exceeds 100 mA, the load short-circuit protection function will be activated (this function will be reset when the power of the Photoelectric Sensor is turned OFF).

Cable End Treatment



* These parts are not provided with models with a -US suffix.

Recommended Crimp Terminal Dimensions (Unit: mm)




Note: Use terminals with insulation tube (recommended crimp terminal: 1.25 to 3.5).

• Others

Terminal Protection Cover (Provided)

The terminal protection cover is designed to improve safety by maintaining the sensitivity properties of the product and by preventing any contact with charged sections while it is being operated with the mode set to the timer mode. Mount the product as shown in the following diagram (mount the Through-beam Model on the Receiver side).




Ambient Conditions (Installation Area)

The E3JM will malfunction if installed in the following places.

- Places where the E3JM is exposed to a dusty environment.
- Places where corrosive gases are produced.



• Places where the E3JM is directly exposed to water, oil, or chemicals.




E3JM

Dimensions

(Unit: mm) Tolerance class IT16 applies to dimensions in this datasheet unless otherwise specified.

Sensors



* Models numbers for Through-beam Sensors (E3JM-10□4(T)-N) are for sets that include both the Emitter and Receiver. The model number of the Emitter is always E3JM-10L-N. Add a "D" to get the model number of the Receiver (example: EE3JM-10DM4-N). Confirm the model numbers of the Emitter and Receiver in Ordering Information.

Accessories (Order separately)

Seal-type Long Slit	Mounting Brackets
E39-S39	Refer to <i>E39-L/E39-S/E39-R</i> for details.
Materials: Polyester 0.1-mm thick	

Read and understand this catalog.

Please read and understand this catalog before purchasing the products. Please consult your OMRON representative if you have any questions or comments.

Warranties.

(a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

(b) Limitations. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE

PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right. (c) Buyer Remedy. Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See <u>http://www.omron.com/global/</u> or contact your Omron representative for published information.

Limitation on Liability; Etc.

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Suitability of Use.

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buver's application or use of the Product. At Buver's request. Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products.

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof

Performance Data.

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications.

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions. Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

In the interest of product improvement, specifications are subject to change without notice.

OMRON Corporation Industrial Automation Company

http://www.ia.omron.com/